

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

RADIATOR COOLANT PRESSURE TESTER

MODEL: YS-064

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

RADIATOR COOLANT PRESSURE TESTER

MODEL:YS-064



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us: **Technical Support and E-Warranty Certificate**
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.



Warning-To reduce the risk of injury, the user must the read instructions manual carefully.

PRODUCTION SCHEDULE

Number	Name	Picture	Specification	quantity
1	Pump		Pressure range 0-35psi/ 0-2.5bar	1
2	2# Test cap			1
3	3# Test cap			1
4	4# Test cap			1
5	5# Test cap			1
6	6# Test cap		Diameter: M50*3.5 English 10 buds	1
7	7# Test cap		Diameter: M45*3.5 English 9 buds	1

8	8# Test cap		Diameter: : M57*3 English 9 buds	1
9	9# Test cap		Diameter: : M62*3 English 9 buds	1
10	10# Test cap		Diameter: : M49*4.5 English 6 buds	1
11	11# Test cap		Diameter: : M46*3.5 English 9 buds	1
12	12# Test cap		Diameter: M51*3 English 8 buds	1
13	13# Test cap		Diameter: M61*4 English 6 buds	1
14	Thermometer		Range: 0-200C/32 - 400°F	1

TECHNICAL PARAMETERS

Model	YS-064
Pressure Range (psi)	0-35
Quantity (PCS)	14
Product Size	340*290*95 mm
Net Weight (kg)	2.2

ATTENTIONS

- Coolant can spray out.
- Before dismantling the pump or the adapter, release the pressure.
- Check the cooling fluid after the pressure test or repair the correct level and frost protection.
- Take care when working on running engines, Loose or baggy clothing can be caught in rotating engine parts.

Study, understand and follow all instructions provided with this product. Read these instructions carefully before installing, operating, servicing or repairing this tool. Keep these instructions in a safe accessible place.

INTENDED USE OF THE TOOL

This kit is designed to test for leakage in vehicle cooling systems, including radiator caps, and for quick change of coolant only. Use as intended only.

- Always read the instructions carefully before using the tool.
- This tool kit is for cooling system maintenance only.
- Ensure the working area has adequate lighting.
- Keep children and unauthorized persons away from the working area
- Keep working area clean and tidy, dry and free from unrelated materials
- DO NOT allow untrained persons to use this tool kit.
- Always wear eye protection that meets OSHA and ANSI Z87.1 standards.
- Always wear gloves when working with the tool.



- Always wear ear protection.
- Disposal: Customers should follow local regulations to handle used/waste parts.
- Do not remove the radiator cap or coolant bottle cap when the engine is hot or at operating temperature. Let the engine cool first failure to heed this warning may cause damage and/or personal injury.

BEFORE USE

DO NOT DISCARD-GIVE TO THE USER

When unpacking, check the parts diagram and part number listing on page 2 to make sure all parts are included. If any parts are missing or damaged, please call your distributor.

DIRECTION FOR USE

1. Cooling System Leakage Test

1.1 Removing the original radiator cap from the radiator or expansion tank.

1.2 Choose the appropriate adapter from the test set and connect it to the radiator or expansion tank.

1.3 Now connect the hand pump(1) to the adapter.

1.4 Press the test pump until pressure of 10 to 15psi is reached (see figure 1+2)

CAUTION: Avoid a pressure of 35psi or more!

Check the pressure gauge. If the displayed value decreases, the leakage is in the cooling system.

The cooling system has a leak if there is a pressure drop or water loss.



2. Radiator Cap Leakage Test

2.1 Remove the original radiator cap.

2.2 Choose the appropriate joint 2a or 2ba and connect it to the radiator cap.

2.3 Press the test pump for few times and watch the pressure gauge. The pressure falls if the cap is defective.(see fig.3)

2.4 Compare the measured pressure values with the standard pressure of the radiator cap.

MAINTENANCE / STORAGE

- Attach the test adapter to the quick coupler of the hand pressure pump, then press the hand pressure pump a few times to push remnant water out of the test adapter.
- Drop pneumatic oil into the air hole of the hand pump end to lubricate the piston of the hand pump.

IMPORTANT NOTE

These instructions do not replace the service literature. You may find additional information in the service-literature. For all tests, vehicle-specific data should be present; without this data can, adequate results are not ensured.

APPLICATIONS



No.






0 Thermometer



1 Pressure Tester Pump with Gauge

3		<p> Buick (LeSabre: 1990-) (Park Avenue: 1991-) Chrysler (Sebring: 1995-) Chevrolet (Venture: 1997-) Dodge (Caravan: 1989-) (Dakota: 1989-) (Startus: 1995-) Jeep Mercedes (W123, W124, W126, W201) Oldsmobile (Silhouette:1990-) Pontiac (Bonneville: 1990-)(Grand Prix:-2003) </p>
4		<p> Acura (Integra: 1991-1993)(Legend: 1989-1990)(NSX: 1995-2004)(SLX: 1997) (Vigor: 1992-1994) (M6: 2008) BMW (Nova: 1985-1998) (Spectrum: 1985-1988) (Sprint: 1986-1988) Chevrolet (Laser:1991-1998) (Sebring: 1996-1998) Chrysler (Avenger: 1995-1999)(Colt: 1984-1991) (Ram 50: 1989-1992) Dodge (Stealth: 1993-1996) (Summit: 1989)(Talon: 1991-1998) Eagle (Aspire:1994-1997)(Escort:1991-2002)(Expedition: 2009-2011) Ford (Explorer:1995-2001)(Explorer Sport Trac:2001-2005)(F-150:2009-2011) (Festiva: 1989-1993)(Mustang:1997-2004)(Probe:1989-1997) (Ranger:1995-2011)(Tempo:1992-1994)(Thunderbird:1992-1995) (Windstar:1996-1999) Geo (Metro: 1989-1993) (Prizm: 1989-1991)(Spectrum: 1989)(Storm: 1990-1993) (Tracker: 1989) GM (Nova, Spectrum, Sprint) Honda (Accord: 1990-1993) (Civic: 1988-1991)(CRX: 1989-1990)(Motorcycles:1991-2004) (Passport:1994-2002)(Prelude:1990-1998) Hyundai (Accent: 1995-2010)(Azera: 2006-2010)(Elantra: 1992-2011)(Entourage: 2007-2008) (Excel: 1986-1994)(Genesis: 2009-2010)(Genesis Coupe: 2010)(Santa Fe: 2002-2010) (Scoupe: 1994)(Sonata: 1989-2011)(Tiburon: 1998-2008)(Tuscon: 2005-2010) (Veracruz: 2007-2010)(XG 350: 2004) Infiniti (FX 35:2003-2007)(G20:1991-2002)(G35:2004-2007)(I30:1997-2000) (I35: 2002-2004)(J30: 1996)(M30: 1990-1992)(M35: 2006-2009)(M45: 2003-2010) (Q45: 1990-2006)(QX4: 1998-2003) Isuzu (Amigo: 1989-2000)(Axiom: 2002-2004)(I-Mark: 1985-1989)(Impulse:1985-1992) (Rodeo: 1991-1998)(Stylus: 1991-1992)(Trooper: 1986-2002)(VehiCROSS: 1999) (Amantii: 2006-2009)(Borrego: 2009)(Forte: 2011)(Optima: 2002-2010) Kia (Rio: 2002-2011)(Rio5: 2007-2011)(Rondo: 2009-2010)(Sedona:2003-2011) (Sephia: 1994-2001)(Sorento: 2003-2011)(Soul: 2010-2011)(Spectra: 2000-2009) (Spectra5: 2005-2009)(Sportage: 1995-2011) Lexus (ES300:1996-2003)(ES330:2005)(LS400:1992)(LX 450:1996-1999) (LX 470: 1998-2005) (SC400: 1992) Lincoln (Navigator: 2009-2011) Mazda (323: 1986-1993)(626: 1985-1999)(929: 1990-1993)(B2000: 1986-1987) (B2200: 1988-1993)(B2300: 2005)(B2500: 1998-2000)(B2600: 1987-1993) (B3000:1996-2007)(B4000: 1995-2006)(CX-9:2007-2010)(Matia:1991-2005) (Millenia:1995-2002)(MPV: 1991-2006)(MX-5 Matia:2006-2012) (MX-6: 1991-1997)(Protegé: 1993-2003)(Protegé 5: 2002-2003)(RX-7: 1986-1995) (RX-8: 2005-2009) Mercury (Capri: 1991-1994)(Cougar: 1989-1992)(Cougar: 1993-1997 w/V6) (Mountaineer: 1997-2000)(Topaz: 1992-1994)(Tracer: 1988-1999) (Villager: 1994-2002) Mitsubishi (3000GT: 1992-1996)(Cordia: 1986-1988)(Diamante: 1992-1995)(Eclipse: 1990-1999) (Galant: 1989-1993)(Mighty Max:1987-1994)(Mirage:1985-1992) (Montero: 1989-1998)(Outlander: 2003-2011)(Outlander Sport: 2011) (Precis: 1988-1992)(Starion:1984-1986)(Tredia: 1986-1988) Mercedes-Benz Nissan (200SX:1984-1988)(240SX:1990-1994)(300ZX:1984-1996)(Altima: 1993-2006) Axxess: 1990)(Cube:2009-2010)(D21:1986-1994)(Frontier:1998-2011) (Maxima:1987-2008)(Murano: 2003-2007)(NX:1991-1993)(Pathfinder:1987-2004) (Pulsar NX: 1987-1989)(Quest: 1994-2009)(Rogue: 2009-2010)(Sentra: 1987-2011) (Stanza: 1987-1992)(Versa: 2007-2011)(Xterra: 2000-2012) (Coit: 1984-1991)(Laser: 1993-1994) Plymouth (Baja: 2004-2005)(Brat: 1983-1987)(DL: 1983-1989)(Forester: 1999-2011) Subaru (GL: 1983-1989)(GL-10: 1985-1989)(Impreza: 1993-2011)(Justy: 1988-1993) (Legacy: 1990-2011)(Loyale: 1990-1992)(Outback: 2000-2011)(RX: 1986) (SVX: 1994-1997)(XT: 1985-1991) Suzuki (Equator:2009-2011)(Samurai: 1986)(Sidekick: 1989-1991)(Swift:1990-1994) (XL-7: 2004-2006) </p>

No.	Image	Application
4		<p>Toyota (4Runner:1986-1995)(Avalon 1995-2004)(Camry:1983-1991). (Camry: 1994-1999 4cylinder)(Celica:1983-1989)(Corolla:1983-1992) (Cressida:1985-1992)(Land cruiser:1993-2007)(MR2:1989-1995)(Previa:1991-1997) (Sienna: 1998-2006)(Solara 1999-2008)(Starlet:1983-1984)(Supra:1987-1990) (T100:1995-1998)(Tacoma: 1996-2004)(Tercel: 1983-1990)</p>
5		<p>Acura (CL:1997-2002)(Integra: 1994-2000)(Legend:1993-1995)(MDX: 2001-2011) (RDx:2009-2012)(RL:1996-2010)(RSX:2002-2005)(TL:1996-2011)(TSX: 2007-2012)</p> <p>Chevrolet (Metro:1999-2000)(Prizm:1998-2002)(Tracker: 1998-2004) (Sebring:2001)</p> <p>Chrysler (Colt: 1993-1994)(Stratus: 2001-2004) (Summit:1992-1996)</p> <p>Dodge (Metro: 1995-1997),(Prizm: 1993-1997)(Tracker:1997)</p> <p>Eagle (Accord:1994-2011)(Civic:1992-2010)(Civic del Sol: 1993-1997)(CR-V:1997-2010) (CR-Z: 2011)(Element: 2003-2010)(Fit:2008-2009)(Insight: 2001-2011) (Odyssey:1998-2010)(Pilot:2003-2011)(Prelude: 1999-2001)(Ridgeline: 2007-2011) (S2000:2006-2009)</p> <p>Geo (Oasis: 1997)(Rodeo: 1999-2000)(Rodeo Sport: 2003)</p> <p>Isuzu (ES250:1990-1991)(ES350:2008-2012)(GS300: 1993-2003)(GS350:2007-2009) (GS430:2004-2007)(GX470:2004-2005)(IS300: 2003)(IS350:2009-2012) (LS430:2001-2003)(LX570:2011-2013)(RX300:1999-2006)(RX350:2008-2010) (RX400h:2006-2008)(SC300:1992-2010)</p> <p>Lexus (Mazda 2: 2011)(Mazda 5:2008-2010)(Protegé:1995-2003)</p> <p>Mazda (ML-class, W163, W164).</p> <p>Mercedes (Diamante:1996-2004)(Eclipse: 2000-2010)(Endeavor: 2006-2011)(Expo: 1992-1995) (Expo LRV: 1992-1994)(Galant:1994-2011)(Mirage: 1993-2002) (Montero Sport:1997-2003)</p> <p>Mitsubishi (Colt: 1992-1994) (Vibe: 2003-2010).</p> <p>Plymouth (FR-S: 2013)(iQ:2012)(iC: 2005-2010)(xA: 2006)</p> <p>Pontiac (B9 Tribeca:2006-2007)(Tribeca: 2008-2010), (Aerio:2003-2007)(Esteem: 1995-2002)(Sidekick: 1991-1998)(Swift:1999-2001) (SX4:2007-2009)(Vitar:1999-2003)(X-90:1996-1998)(XL-7:2002-2003)</p> <p>Scion (4Runner:1969-2011)(Avalon: 2005-2010)(Camry: 1990-1991 V6 w/ auto.trans.) (Camry:1992-2011)(Celica:1990-1999)(Corolla:1993-2012)(Echo: 2001-2005) (FJ Cruiser:2007-2010)(Highlander: 2001-2011)(Land Cruiser: 2009)(Matrix: 2003-2011) (Paseo: 1992-1998)(Pnus: 2001-2009)(RAV4:1996-2003)(Sequoia: 2001-2011) (Sienna: 2007-2011)(Supra: 1990-1998)(Tacoma:2005-2011)(Tercel: 1991-1998) (Tundra: 2000-2011)(Venza: 2009-2011)(Yaris: 2008-2011)</p> <p>Suzuki (Touareg: 2004)</p> <p>Toyota</p> <p>VW</p>
6		<p>Cadillac (Catera:1997-2001)</p> <p>Chevrolet (Aveo: 2004-2011)(Aveo5: 2006-2011)(Epica: 2004)</p> <p>Daewoo (Leganza: 1999-2002)(Lanos: 1999-2002)(Nubira:1999-2002)</p> <p>Ford (Contour:1995-2000)(Fiesta:1995-)(Focus:1998-)(Fusion:2006-)</p> <p>GM (Achieva)(Skylark)(Grand Am: 1992-2002)</p> <p>Jaguar (All:1990-1994)(XJ8:1998-2001)(XJR: 1998-2001)(XK8:1997-2006)(XKR: 2000-2006) (X-Type:2002-2007)</p> <p>Jeep</p> <p>Land Rover (Discovery:1989-2004)(Range Rover:1988-1994)</p> <p>Mercedes-Benz (ML-Class: 1997-2011)</p> <p>Mercury (Mistique:1995-2000)</p> <p>Pontiac (Le Mans:1988-1993)(G3:2009)(Wave: 2005)(Wave5: 2005)</p> <p>Porsche (911:1999-)(Boxter:1997-)</p> <p>Saab (900:1994-1998)(9-3:1999-2003)(9-5:1999-2008)</p> <p>Saturn (L100:2001-2002)(L200:2001-2003)(L300:2001-2005)(L300-1:2004)(L300-2:2004) (L300-3:2004)(LS: 2000)(LS1:2000)(LS2:2000)(LW1:2000)(LW2:2000) (LW200:2001-2003)(LW300:2001-2003)(Vue: 2002)</p> <p>Suzuki (Forenza: 2004-2008)(Reno: 2005-2008)(Swift +: 2004)(Verona: 2004-2005)</p>
7		<p>Alfa Romeo (145-930:1994-2001)(146-930:1994-2001)(164-164:1987-1998)(166-936:1998) (33-907A:1990-1994)(33 sportwagon-907B:1990-1994)(GTV-916C:1994) (Spider-916S:1994-2005)</p> <p>Citroën (Jumper Box 230L:1994-2002)(Jumper Bus 230P:1994-2002) (Jumper Platform / Chassis 230:1994-2002)</p> <p>Fiat (Coupe FA/175:1993-2000)(Croma-154:1985-1996)(Ducato Box-230L:1994-2002) (Ducato Box-244:2002)(Ducato Bus-230:1994-2002)(Ducato Bus-244Z: 2002) (Ducato Platform / Chassis 230:1994-2002)</p> <p>Lancia (Delta II-836:1993-1999)(Kappa-938A:1994-2001)(Kappa Coupe-838:1996-2001) (Kappa SW-838B:1996-2001)(Thema-834:1984-1994)(Thema SW-834:1987-1994) (S: 2002-)</p> <p>Mini Cooper (S: 2002-)</p> <p>Peugeot (206:1999-)(307:2004-)(406:1999-)(407:2004-)(807:2004-) (Boxer Box-230L:1994-2002)(Boxer Bus-230P:1994-2002) (Boxer platform / Chassis-ZCT:1994-2002)</p> <p>Renault (All:1985-1987)(Avantime:2002-)(Espace:2002-)</p> <p>Saab (900:1978-1993)(9000:1986-1998)</p> <p>Sterling (All:1987-1991)</p> <p>Jeep</p> <p>Volvo (Passenger vehicles w/threaded neck)</p>

No.	Image	Application
8		VW (Vento)(T4)(Passat:1990-1997)(Beetle)(Sharan)(Cabrio: 1995-2002) (Corrado: 1990-1994)(Eurovan:1993-2003)(Golf: 1990-1999) (1990-1998: with female thread on filler neck of expansion tank - except 1998 Passat & New Beetle)(Jetta:1990-1999)
9		Audi (A3:2006-2012)(A3-8P:2003)(A3 Convertible: 2008)(A3 Sportback-8PA: 2004) (A4:1996-2012)(A4-8EC.B7:2004-2008)(A4 Avant-8ED.B7:2004-2008) (A4 Quattro:1996-2012)(A5: 2011-2012)(A5 Quattro: 2008-2012)(A6:1998-2012) (A6 Quattro:1998-2011)(A7 Quattro:2012)(A8 Quattro: 2004-2010) (Allroad Quattro: 2001-2005)(Q5:2009-2012)(Q7:2007-2012)(R8:2008-2012) (RS4:2007-2008)(RS6:2003)(S4:2000-2012)(S5:2008-2012)(S6:2002-2011) (S8:2007-2009)(TT: 2000-2009)(TT-8J3:2006)(TT-8N3:1998-2006) (TT Quattro:2000-2013)(TT Roadster-8J9: 2007)(TT Roadster 8N9:1999-2006) (345) (Cayenne) BMW Porsche SEAT (Altea-5P1:2004)(Cordoba-6K2:1999-2002)(Cordoba-6L2:2002-2009) (Ibiza III-6K1:1999-2002)(Ibiza IV-6L1:2002-2009)(Leon-1M1:1999-2006) (Leon 1P1:2005)(Toledo-1L:1991-1999)(Toledo II-1M2:1999-2006) Skoda (Fabia:2006)(Fabia-6Y2:1999-2008)(Fabia Combi:2007)(Fabia Combi-6Y5:2000-2007) (Fabia Praktik: 2001-2007)(Fabia Saloon-6Y3:1999-2007)(Laura-1Z3:2004) (Octavia 1U2:1996-2010)(Octavia Combi-1U5:1998-2010)(Octavia Combi-1Z5: 2004) (Roomster-5J: 2006)(Superb-3T4:2008)(Superb-3U4:2002-2008) (Superb Estate: 3T5: 2009) VW (Beetle:1998-2012)(Caddy III Box-2KA, 2KH,2CA,2CH: 2004) (Caddy III Estate-2KB, 2KJ,2CB,2CJ: 2004)(CC:2009-2013)(Crafter 30-35 Bus 2E: 2006) (Crafter 30-50 Box 2E: 2006)(Crafter 30-50 Platform / Chassis 2F)(Eos: 2007-2012) (Eos-1F7,1F8:2006)(Fox-5Z1,5Z3:2003)(Golf: 1999-2012)(Golf Plus-5M1,521:2005) (Golf V-1K1:2003-2009)(Golf V Variant(1K5:2007)(GTI: 2006-2013)(Jetta:1997-2012) (Jetta I Saloon-1K2:2005-2010)(LT 28-35 II Bus-2DM:1996-2006) (LT 28-46 II Box-2DX0AE:1996-2006)(LT 28-46 II Platform / Chassis 2DX0FE:1996-2006) (Multivan Mk V-7HM,7HN,7EF,7EM,7EN:2003)(New Beetle-9C1,1C1:1998) (New Beetle Convertible-1Y7: 2002-2010)(Passat: 1998-2012)(Passat-3B3:2000-2005) (Passat-3C2:2005)(Passat Variant-3B6:2000-2005)(Passat Varian 3C5:2005) (Polo-9N: 2001)(Polo Saloon: 2002)(R32:2008)(Rabbit: 2006-2009)(Tiguan: 2009) (Touareg: 2004-2012)(Touran-1T1,1T2,1T3:2003) (Transporter / Caravelle MK V Bus-7HB,7HJ,7EB,7EJ,7EF:2003) (Transporter MK V Box- 7HA,7HH,7EA,7EH:2003) (Transporter MK V Platform / Chassis-7JD,7JE,7JL,7JY,7JZ: 2003)
10		BMW (3-E30:1982-1992)(3-E36:1990-1998)(3-E46:1998-2005)(3-E90:2005) (3 Compact-E36:1994-2000)(3 Compact-E46:2001-2005) (3 Convertible-E30:1985-1993)(3 Convertible -E36:1993-1999) (3 Convertible-E46:2000)(3 Coupe-E36:1992-1999)(3 Coupe-E46:1999) (3 Touring -E30:1987-1994)(3 Touring-E36:1995-1999)(3 Touring-E46:1999-2005) (3 Touring-E91:2005)(5-E28:1980-1990)(5-E34:1987-1995)(5-E39:1995-2003) (5-E60:2003)(5 Touring-E34:1991-1997)(5 touring-E39:1997-2004) (7-E23:1977-1986)(7-E32:1986-1994)(7-E38:1994-2001)(7 E65, E66:2001) (8-E31:1990-1999)(X3-E83:2004)(X3-E53:2000)(Z3-E36:1995-2003) (Z3 Coupe-E36:1997-2003)(Z4-E85:2003)(Z4 Coupe-E86:2006) (Z8-E53:2000-2003)(Brilliance 3 Series-E46:2003-2005)(Brilliance 3 Series-E90: 2004) Land Rover (Freelander- LN: 1998)(Range Rover III- LM: 2002)
11		Audi (1975-1993: w/male thread on expansion tank) VW (1975-1993: w/male thrd on exp.tank)(Golf:1983-1992)(Cabriolet:1985-1993) (Dasher:1980-1981)(Fox: 1987-1993)(Golf:1985-1990)(Jetta:1980-1990) (Quantum:1980-1988)(Rabbit:1975)(Rabbit Convertible: 1980-1984) (Scirocco:1975-1988)
12		Caterham (Super Seven: 1990-1999) Ford (Cougar:1998-2001)(Mondeo: 1996-2007)(Mondeo Estate Wagon: 1996-2007) (Transit 260: 2000-2006)(Transit 280:2000-2006)(Transit 300:2000-2006) (Transit 330: 2000-2006)(Transit 350: 2000-2006)(Transit 425: 2003-2006) (Transit 430: 2001-2006)(Transit Tourneo: 2000-2006)(CourierI: 1990-1995) (Courier IV: 1995-2001)(Escort 55 IV:1986-1990)(Escort 55 VI:1994-2000) (Escort 75 VI:1994-2000)(Escort IV: 1986-1990)(Escort V: 1990-1996) (Escort VI: 1995-2000)(Fiesta Classic: 1987-1989)(Fiestall: 1989-1989) (Fiesta III: 1989-1996)(Fiesta IV: 1995-1999)(Fiesta V:1999-2002) (Fiesta Van II:1987-1989)(Fiesta Van III: 1989-1996)(Fiesta Van IV:1995-2002) (Fiesta Van V: 1999-2002)(Fiesta Van VI: 2002-2008)(Fiesta VI: 2002-2008) (Focus I:1998-2005)(Focus Wagon I:1998-2005)(Fusion: 2002-2005) (Granada Scorprio:1985-1994)(Ka I:1996-2005)(Mondeo I: 1993-1996) (MondeoII: 1996-1998)(Mondeo Wagon I:1993-1996) (Mondeo Wagon II: 1996-2000)(Orion II:1986-1990)(Orion III:1990-1993) (P100 Sierra:1989-1994)(Puma):1997-2002)(Scopio I:1984-1994) (Scopio II: 1994-1998)(Sierra Cosworth II:1987-1993)(Sierra I:1984-1987) (Sierra II:1987-1993)(Sierra Sapphire II:1987-1993)(Streetka I: 2003-2005) (Transit 100:1994-1999)(Transit 120:1994-1999)(Transit 150:1994-1999) (Transit 190:1994-1999)(Transit Connect: 2002-) Land Rover Mazda (2:2002-2007)(121:1996-2002)

No.	Image	Application
12		<p>Opel (Agila: 2000-2008)(Ascona B: 1978-1981)(Ascona C: 1981-1988) (Astra Cabrio F: 1993-2001)(Astra Cabrio G: 2001-2005)(Astra Classic F: 1998-2002) (Astra Coupe G: 1999-2005)(Astra F: 1991-1998)(Astra G: 1998-2005) (Astra H: 2004-2005)(Astra Van F: 1991-1998)(Astra Van G: 1998-2004) (Calibra: 1989-1998)(Combo Corsa B: 1992-2001)(Combo Corsa C: 2001-2004) (Corsa A: 1982-1993)(Corsa B: 1993-2000)(Corsa C: 2000-2006) (Corsa Van A: 1982-1994)(Corsa Van B: 1994-2001)(Corsa Van C: 2000-2003) (Frontera A: 1991-1998)(Kadett D: 1979-1984)(Kadett E: 1984-1992) (Kadett Van E: 1984-1992)(Manta A: 1974-1975)(Manta B: 1975-1988) (Meriva: 2003-2005)(Monza: 1981-1987)(Omega A: 1986-1994)(Omega B: 1994-2003) (Senator A: 1981-1987)(Senator B: 1987-1993)(Tigra A: 1994-2001)(Tigra B: 2004) (Vectra A: 1988-1995)(Vectra B: 1995-2003)(Zafira A: 1999-2005)(Zafira Van: 2002-2003) (900 II: 1993-1998)</p> <p>Saab (Favorit: 1989-1995)(Favorit Forman: 1993-1995)(Felicia-6U1: 1994-2000)</p> <p>Skoda (Astra Cabrio III: 1991-2001)(Astra Cabrio IV: 2001-2007)(Astra Coupe IV: 1999-2005) (Astra I: 1979-1984)(Astra II: 1984-1991)(Astra III: 1991-1998)(Astra IV: 1998-2005) (Astra Van III: 1991-1996)(Astra Van IV: 1998-2005)(Astramax: 1985-1991) (Astravan I 1982-1984)(Astravan II 1984-1991)(Belmont: 1986-1991) (Calibra: 1990-1998)(Carlton: 1983-1994)(Cavalier II: 1981-1988) (Cavalier III: 1988-1995)(Combo: 1993-2004)(Combo Crew Van: 2001-2006) (Corsa I: 1993-2000)(Corsa II: 2000-2006)(Corsa Van I: 1993-2001) (Corsa Van II: 2001-2006)(Frontera A: 1991-1998)(Meriva: 1982-1993) (Nova: 1982-1993)(Nova Van: 1990-1993)(Omega: 1994-2003)(Senator: 1987-1993) (Tigra: 1994-2004)(Vectra I: 1999-2005)(Zafira A: 1999-2005)(Zafira B: 2005-2007)</p> <p>Ssangyong</p> <p>Vauxhall</p>
13		<p>Chrysler (Crossfire: 2004-) Mercedes (w/ thread filler neck on expansion tank, except M-Class)(300SE: 1992-1993) (400SE: 1992)(400SEL: 1993)(500SEC: 1993)(500SEL: 1992-1993) (500SL: 1990-1993)(600SEC: 1993)(600SEL: 1992-1993)(600SL: 1993)(C230: 2002) (C240: 2001-2005)(C280: 1994-2007)(C300: 2008-2009)(C32 AMG: 2002-2004) (C320: 2001-2005)(C350: 2008)(C36 AMG: 1995-1997)(C43 AMG: 1998-2000) (CL500: 1998-2006)(CL55 AMG: 2001-2002)(CL600: 1998-2006) (CL65 AMG: 2005-2006)(CLK 320: 1998-2005)(CLK 430: 1999-2003) (CLK500: 2003-2005)(CLK55 AMG: 2001-2005)(E300: 1996-1997)(E320: 1996-2005) (E350: 2006-2009)(E420: 1997)(E430: 1998-2002)(E500: 2003-2006) (E55 AMG: 1999-2002)(E550: 2009)(G500: 2002-2005)(G55 AMG: 2003-2005) (GL450: 2007-2008)(ML350: 2006-2008)(ML500: 2006-2007)(ML550: 2008-2009) (S320: 1994-1999)(S350: 1994-2006)(S420: 1994-1999)(S500: 1994-2006) (S55 AMG: 2001-2006)(S600: 1994-2006)(S65 AMG: 2006)(SL320: 1994-1997) (SL500: 1994-1998)(SL600: 1994-2002)(SLK280: 2006-2008)(SLK32 AMG: 2002-2004) (SLK 320: 2001-2004)(SLK 350: 2006-2008)(SLK55 AMG: 2008)</p>
14		<p>Ford (Mondeo: 2000-2007)(Focus: 2000-2005)(C-MAX03)(Contour: 1995-2000) Mercury (Cougar: 1999)(Mystique: 1995-1999)</p>

Made In China

VEVOR[®]
TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate
www.vevor.com/support