

Inflatable Tent User Manual

1. Installation



- 1.1 For instructions related to using big power blower (750W/950W /1100W/1500W) to inflate the booth, refer to the picture above.
- 1.2 Open the zipper of the transparent door, drive the vehicle inside the booth from the clear door.
- 1.3 Zip up the transparent door and make sure all other zippers are securely zipped.
- 1.4 Start the air cycle blower(350W/330W) when beginning spray work.
- 1.5 The transparent exit door on the left side will help you evacuate the booth quickly in case of an accident.

2. Fixing the Booth



Picture

- 2.1 Use a sandbag or a nail to fix the D ring below the tubes, refer to the picture above.
- 2.2 Use ropes and heavy things to fix the position of the high D ring, refer to the picture above.

3. Attention

- 3.1 Don't use it outdoors during heavy rain or typhoons!
- 3.2 Please protect the booth from sharp objects, open fires, and other hazards.
- 3.3 Please keep the product stored in dry and well-ventilated areas when not in use.

CE Certification, Model: IT01

Warning:

- 1. Make sure children are not left alone by the product.
- 2. Prevent children and unauthorized personnel from operating the product.

3. Keep away from children.