## **VEVOR®**

# BUTTON MAKER MACHINE INSTRUCTION MANUAL

## **VEVOR®**

### BUTTON MAKER MACHINE INSTRUCTION MANUAL

BJS-25-RD-01 BJS-32-RD-01 BJS-58-RD-01 BJS-75-RD-01



#### **NEED HELP? CONTACT US!**

Have product questions? Need technical support? Please feel free to contact us:




This is the original instruction. Please read all manual instructions carefully before operating. VEVOR reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

#### **SAFETY REMINDER**

- 1. This badge machine is only applied for the intended purpose. Don't apply in other applications which exceed safety considerations.
- 2. Children cannot operate this product unless accompanied by an adult.
- 3. Pay attention to safety during operation, and avoid crushing fingers.

#### **COMPONENTS**









#### **INSTALLATION STEPS**



1. Use Allen key to fix machine bottom plate.



2. Revolve and twist machine handle in.



Install the up mold on the machine, mold side pin align to back and upward push, the magnetism automati cally attached.



4. Lift up the up mold by align thehole, and then slide the down mold in the base groove.



5. Upward twist the positioning screw to the suitable depth from the bottom. (both left and right position)



6. Installation is finished and able to start manufacture.

#### **MANUFACTURE STEPS**



1. Put "Tin up cover"--"Paper"(pattern levelly placed)--"Transparent plastic film" into the left mold in sequence, then push the down mold to bottom from left to right till up and down mold aligned.



2. Use one hand to hold the machine body first then stable the machine body by the handle, another hand press the machine handle till down press to be bottom. (Special attention: this time down pressed up mold hinge is in a separate state.)



3. The upper mold hinge is in a separate state.



Put the plastic back plate into the right mold (Attention: The pin should be level without protruding. The upside words upward placed according to the mold side triangle indication mark), push the down mold to the bottom from left to right till up and down mold aligned.



Hand holds the machine body, right hand down press the handle until up and down mold merged to bottom.



Now the up mold hinge is in merged state, and the pin passes through the hole.



Manufacture finished



Special Attention: If the metal back plate is used, the plastic washer needs to be placed in the right mold groove. (Only required when using 58, 75 gauge metal back plate.)

#### FAILURE AND TROUBLESHOOTING

Failure Appearance	Possible Reasons	Troubleshooting
First time downward press iron cover and not absorbed to up mold	Unsuitable operating method     Too much lubricating oil in the     up mold	1. First time downward press up mold hinge is open status 2. Use clean cloth or tissue completely wipe it if found too much lubricating oil on the up mold 3. The up and down mold must be on the same vertical line when closing
Second downward press part not wrapped in	Unsuitable operating method     High mold friction force     Unsuitable paper thickness     Up mold screws loosen	1. The up and down mold must be on the same vertical line when closing 2. Evenly coat lubricating oil in the up and down mold internal holes 3. Use the stipulated thickness paper 4. Place the up mold on the machine body, use the complimentary Allen key to fix the screws in the up mold internal hole center.
Not tightly press the badge, pressed in but not firm	1. The downward press is not in place, not press to the bottom 2. Paper is thinner 3. ( 25mm, 32mm ) Configured metal back consumables do not place the washer	Need press to the bottom when downward pressing     Change to use a slightly thicker paper     Right side mold place 2mm thickness washer when using the metal back consumables
Noise during pressing manufacture	High friction force between molds	Evenly coat lubricating oil in the up and down mold internal holes
Up mold unable to lift after pressing manufacture, blocked	Up and down mold position deviated     The paper is incorrectly cut round or blocked by a foreign object.	Use a sharp tool (such as a straight screwdriver) to align to middle merge position clearance which is between up and down mold, and pry open with the object like a hammer (Attention: Just tap it, generally, it will not be too tightened).
Up mold and down mold are not at the same vertical line when closed	I. Incorrect mold position     Reversely installed mold slide rail	Push mold position over or not on position     Reversely installed the mold slide rail into the machine

#### **MODEL AND PARAMETER**

Product Model Model	BJS-25-RD-01	BJS-32-RD-01	BJS-58-RD-01	BJS-75-RD-01
Manufactured Badge Specification	Ф25	Ф32	Ф58	Ф75
Machine Body Color	Red	Red	Red	Red
Paper Requirements	127-157g Copper Plate Paper	127-157g Copper Plate Paper	127-157g Copper Plate Paper	127-157g Copper Plate Paper
Accessories With Machine	1. Ф25 Iron Bottom Back Plate * 250 Pieces 2. Ф25 Plastic Bottom Back Plate * 250 Pieces 3. Ф25Tin Up Cover *500 Pieces 4. Ф25 Blank Round Paper * 50 Pieces 5. Ф25 Transparent Film * 500 Pieces 6. Ф25 Round Cutter * 1 Piece 7. Allen Key * 2 Pieces 8. Magic Book *1 Set 9. Instruction *1 Set	1. Ф32 Iron Bottom Back Plate * 250 Pieces 2. Ф32 Plastic Bottom Back Plate * 250 Pieces 3. Ф32Tin Up Cover *500 Pieces 4. Ф32 Blank Round Paper * 50 Pieces 5. Ф32 Transparent Film * 500 Pieces 6. Ф32 Round Cutter * 1 Piece 7. Allen Key * 2 Pieces 8. Magic Book *1 Set 9. Instruction *1 Set	1. Ф58 Iron Bottom Back Plate * 250 Pieces 2. Ф58 Plastic Bottom Back Plate * 250 Pieces 3. Ф58Tin Up Cover *500 Pieces 4. Ф58 Blank Round Paper * 50 Pieces 5. Ф58 Transparent Film * 500 Pieces 6. Ф58 Round Cutter * 1 Piece 7. Allen Key * 2 Pieces 8. Magic Book *1 Set 9. Washer * 2 Pieces 10. Instruction *1 Set	1. Ф75 Iron Bottom Back Plate * 250 Pieces 2. Ф75 Plastic Bottom Back Plate * 250 Pieces 3. Ф75Tin Up Cover *500 Pieces 4. Ф75 Blank Round Paper * 50 Pieces 5. Ф75 Transparent Film * 500 Pieces 6. Ф75 Round Cutter * 1 Piece 7. Allen Key * 2 Pieces 8. Magic Book *1 Set 9. Washer * 2 Pieces 10. Instruction *1 Set

Manufacture: Taizhou Huangyan Junmao Machinery Technology Co.,Ltd.

Address: No.91, Shiyuan Road, Nancheng Street, Huangyan District, Taizhou, Zhejiang Province.

Importer: WAITCHX

Address: 250 bis boulevard Saint-Germain 75007 Paris

Importer: FREE MOOD LTD

Address: 2 Holywell Lane, London, England, EC2A 3ET

EC REP

EUREP GmbH Unterlettenweg 1a, 85051 Ingolstadt, Germany

EUREP UK LTD

UNIT 2264, 100 OCK STREET, ABINGDON OXFORDSHIRE ENGLAND OX14 5DH

Made in China



E-mail: CustomerService@vevor.com