Manual for Rotor trimmer

The Rotor Leaf Trimmer is used for separating protruding excess leaves and cutting twigs from a variety of plants and flowers. They can also be used to cut plants and bushes like rosemary, oregano, basil, mint, lavender, coriander, parsley, and to prepare essential oils and mixed flowers for aromatherapy and potpourri. With just a few electric drives, small leaves will be blown into the gear box by inside fan for easy disposing.

Operating Process



Switch on:

Connecting the power supply and turn on the leaf trimmer with the green button



Selecting the speed:

Speed 1: 1050r/min Speed 2: 1250r/min Speed 3: 1450r/min



Placing the untrimmed plants on the blade grate:

- 1. Place plants on top of the blade grate
- 2. Move back-and-forth and rotate it at the same time.
- 3. The fan will roll the plants into the gearbox, and blades cut the plants.

Notice: Must wearing the gloves when operating this step




Getting the large buds / fruit:

Remove the stainless steel bezel, buds / fruit will be swept into the pipeline.



Overturning the trimmer:

Overturn the trimmer to get the buds/fruit is also available. When reversing it, the electricity will be cut off automatically to protect the worker's safety.



Collecting leaves for future use:

When the catch bag is full, remove it and pour the leaves or petals in another bag or just use another catch bag under the gear box.

Depending on the type of plants, the trimming can be used for the preparation of plants' essential oils.



Switch Off:

Switch off the trimmer by pressing the green button, and then cut off the electricity.



WARNINGS:

- ◆ Never place your fingers, gloves or any other body part in contact with the grate or the blade.
- Never apply pressure on the grate.
- ◆ Do not use scissors, knives or any instrument above the grate.
- ◆ Safety glasses and gloves are required at all time.
- ◆ The gloves have to be tight enough so they don't get inside the grate slots. A loose glove is dangerous.

Please Note:

The manufacturer does not accept any responsibility for damages caused to or by the trimmers resulting from an inadequate use or assembly. Use the trimmers in accordance with existing laws and regulations.