
Congratulations on purchasing the latest version of Motor Tent that is designed to keep your ride clean

Manual for MOTOR TENT

SIZE







The Motor Tent comes partially assembled, so it Start by checking the various compoents listed in the right chart to familiarize yourself with the parts and make sure that you have all of them.

Step1

Lay assembly A on your right and B on your left with the shortest tubes pointing in front of you and ribs laying tanned out on the floor.





Step 2 Connect the E tubes on to the A&B parte with angled ends on upper rib using F,G & H fasteners.



Connect D. Then lift the assemblies with all ribs and connect Cacross the Aor B frames

Leave The last C tube uninstalled for this step as the






step5


step4

Check to ensure that the tent cover is spreead in the right direction.

Let the 2 unconnected tubes pass through ground sleeves of the cover




Let the last C tube pass through the ground sieeve of the cover and connect it with assembly A and B



step6

Fold the cover backwards over the farme.wrap the velcros around the ribs as appropriate.and tidy up the whole tent.



Secure the frame

Weights can be placed on the flat bar connected to the D plate. Bolts can be used to fasten the swivel plates of A&B to concrete or other firm surface

Fold Down and Storage

The Motor tent Is designed to fold down for storage as needed. While the Motor tent is still fully assembled.remove the bolts for the A frame and take out the H tubes.The motor tent can chen collapse closed pivoting on the A and B base assemblies. Tie the ribs togrther at the top and then you can easily move it around.

We wish you many years of quality Motorcycle Storage with you Motor Tent