

Inflatable Tent User Manual

1. Installation



- 1.1 Using big power blower(750W/950W/1100W/1500w)to inflate the booth, refer to above picture.
- 1.2 Open the zipper of the transparent door, drive the vehicle inside the booth from the clear door.
- 1.3 Zip up the transparent door, check and zip up all the zipper of the booth.
- 1.4 Open air cycle blower(350W/330W) when starting spray work.
- 1.5 The Transparent exit door on the left side will help you evacuate the booth quickly in case of an accident.

2. FixingtheBooth



- 2.1 Using sand bag or nail to fix the D ring below the tubes, refer to above picture.
- 2.2 Using ropes and heavy thing to fix the high D ring, refer to above picture.

3. Matters need to attention

- 3.1 Don't use outdoor on heavy rain day or typhoon day!
- 3.2 Please protect the booth from sharp thing, open fire or other dangerous thing!
- 3.3 Pls restore it in a dry and well ventilated place when do not use.

CE Certification, Model: IT01

Warning: Children no admission