

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

CHAINSAW SHARPENER JIG KIT USER MANUAL

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

CHAINSAW SHARPENER JIG KIT

Model: CY-SDGJ1



Note: the quantity of parts shown in the manual is the actual usage and the unused parts are spare parts.

NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

 CustomerService@vevor.com

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.



Warning-To reduce the risk of injury, user must read instructions manual carefully.

IMPORTANT SAFEGUARDS

Thank you for using this product. In order to make sure that you can operate the machine correctly, read this instruction carefully before operation and keep it properly for future reference. Please be sure to read the precautions and safety rules in this page to ensure your safe use.

This manual will outline safety warnings and precautions, operating, maintenance and cleaning. The warnings and instructions reviewed in this manual cannot cover all possible conditions and situations that may occur. Caution and common sense are not built into this product, since we believe that the uses will comply with these codes.

Please read ALL the instructions before using your machine.

1. **Do NOT** let children and minors get close to or touch the product.
2. **Do NOT** immerse the appliance in water or any other liquid.
3. Using any accessories or attachments that are not provided or recommended by the manufacturer may cause injury.
4. Do not attempt to modify the machine in any way.
5. If the machine is not to be used for a long period of time, clean and cover it and store it in a dry and safe place.
6. **KEEP IT OUT OF CHILDREN'S REACH.**
7. Avoid using it in the presence of flammable liquids, gases, dust or other explosive situations.
8. Children shall not play with the machine alone. Cleaning and user maintenance shall not be made by children without supervision.
9. The machine must never be left unattended during operation or cleaning.
10. Make sure that the machine is always placed on a firm, level and fire retardant surface, and also placed far away from combustibles.
11. While every effort has been made in the manufacture of your machine to remove any sharp edge, you should handle all components with care in order to avoid accidental injury.

12. Keep away from flammable material and fluids such as petroleum, alcohol, diesel fuel, kerosene and charcoal lighter fluid or vehicles while in use. Do not use these materials to light or relight also.

13. **DO NOT CLEAN IT WITH ANY ABRASIVE MATERIAL.**

14. **DO NOT** wear loose clothing, and ensure that long hair is tied back when around the machine when it is hot or in use.

15. The machine should only be repaired or serviced by an authorized Service Engineer and only genuine approved spare parts should be used.

16. This product cannot be used for other purposes.

17. Not suitable for commercial use.

18. Wear safety goggles and heavy-duty work gloves during assembly and using.

19. Do not assemble when tired or when under the influence of alcohol, drugs or medication.

WARNING! Remove all packaging materials and keep them for future use. Packaging materials are not a toy.

WARNING! Don't let children and pets play with the packaging materials. If they swallow the packaging materials, they will suffocate!

WARNING! Keep children and pets away. Children must not operate or play near this machine.

WARNING! Failure to follow instructions could result in death, serious bodily injury and/or property loss.

OPERATING INSTRUCTIONS

1. Please dispose of all plastic bags carefully and keep them away from children.

2. Check all components provided according to the list in this manual.

3. Make sure you have all of the parts listed. If not, contact your local store who will be able to help you.

ATTENTION!


Whilst every care is taken in the manufacture of this product, care must be taken during assembly in case sharp edges are present.

NOTE!

Wear safety goggles and heavy-duty work gloves during assembly and using.


STEP 1

Side A



1. Place chainsaw on flat surface pointing towards you. Place tool on saw with side set screws on side A. Make sure 3 black screws are loosened.

STEP 2



2. Put the sharpener on the saw blade and tighten 3 black screws. Insert the burr to the sleeve guide, sticking with the sawtooth.


Note: Wear safety goggles and heavy-duty work gloves during assembly and using.

STEP 3



3. The carbide should now be inserted into the guide. The tool should rock on the carbide. Find balance point where neither end of tool touches chain. Tighten the side screw to hold the pawl against the sawtooth.

STEP 4




4. Rotate the handle to get the tooth sharper. Pull out carbide. Pull chain forward to test that it moves freely through tool. If not, repeat step 3 and find correct balance point.

STEP 5



5. Reinsert earbide into guide and chain tooth. Tighten middle side set screw to apply slight side pressure via the spring clip to keep the chain vertical if needed.

STEP 6



6. Tighten the Rear thumb screw until the Pawl pushes against the chain's tooth.

STEP 7



7. Pull carbide out and tighten rear thumb screw approx. 1/4turn (This adjustment controls the amount of material shaved from the chain tooth)Turn the handle and push the carbide completely into the tooth.

Note: Turn the handle clockwise Never counter clock wise. Carbide should

STEP 8



8. Pull carbide out and put chain forward to sharpen the next tooth,The thumb screw should not be adjusted again,This insures all teeth are sharpened the same amount making the entire chain uniform and precise.

CLEANING MAINTENANCE AND STORAGE

1. Ensure the machine of the saw blade is turned off and remove the product from the chain lock.
2. Use a brush to clean, wipe the surface with a damp (not wet) cloth or wipe dry with a clean lint free cotton cloth.
3. Keep the product dry after cleaning
4. Put the cleaned products and accessories into the tool bag

Note: Only clean when the product is not working.

Note: Wear safety goggles and heavy-duty work gloves during cleaning.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Support and E-Warranty Certificate

www.vevor.com/support

Made in China