

Technical Support and E-Warranty Certificate www.vevor.com/support

OSCILLATING SAW BLADE USER MANUAL

Model: QH-30

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and doses not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.



Thanks for purchasing one of our products, please read carefully the assembly instructions before the installation.

This tool is not only for brand VEVOR, but also for other brands with the same function, please feel free to buy.

NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

ASSEMBLY AND USE PRECAUTIONS

- 1. Assemble needs to follow these instructions. Incorrect assembly can be a hazard
- 2.Do not assemble when tired or under the influence of alcohol, drugs or medication.
- 3. Keep bystanders out of the area in use.
- 4.Can only be used in cutting wood and plastic.

WARNING: TO PREVENT SERIOUS INJURY AND DEATH FROM


- 1. This product is not a toy. Do not allow children to play with or approach this item.
- 2.Inspect before every use. Do not use it if parts are loose or damaged.
- 3. Wear safety goggles and heavy-duty work gloves in use.

PRODUCT PARAMETERS

Image	Product Size/mm	Material	Features	Quantity /pcs
The same	78×52	SS	Cutting Wood Plastic	2
	88×68	HCS	Cutting Wood Plastic	2
	90×20	HCS	Cutting Wood Plastic	2
	90×64	HCS	Cutting Wood Plastic	2
A Book	90×44	BIM	Cutting Wood Plastic	4
The state of the s	90×34	ВІМ	Cutting Wood Plastic	4
	90×44	HCS	Cutting Wood Plastic	4
The state of the s	90×34	HCS	Cutting Wood Plastic	10

INSTRUCTIONS FOR THE USE OF ACCESSORIES

Due to our saw blades may get loose in some oscillating tools, to ensure our saw blades reach their full potential, we included 2 adapters in our sets, Here are instruction:





Technical Support and E-Warranty Certificate www.vevor.com/support Made In China