

Technical Support and E-Warranty Certificate www.vevor.com/support

TRAILER COUPLER

MODEL: 1BJY-TC-04C / 1BJY-TC-07C

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and doses not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.



TRAILER COUPLER

MODEL: 1BJY-TC-04C / 1BJY-TC-07C





NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

TechnicalSupport and E-Warranty Certificate www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFETY INSTRUCTIONS

AWARNING


- 1. Safety chains must be used.
- 2. Be sure to take good protection during welding work.
- 3. Be sure to check that the bolts are tight.
- 4. Be sure to match the corresponding trailer ball.
- After towing for 50 miles, check coupler for tightness on ball. Always check tighness before towing. Be sure coupler handle is in locked position.
- 6. Do not exceed the gross trailer weight capacity.

MODEL AND PARAMETERS

Model	1BJY-TC-04C	1BJY-TC-07C
Capacity	3500lbs	5000lbs
Ball Size	2inch	2inch
Applicable Channel	2inch	3inch
Color	Silvery White	Silvery White

STRUCTURE DIAGRAM

Take 1BJY-TC-04C for example.




1.Ball Socket 2.Safety Pin 3.Handle 4.Channel

COMPONENTS

No.	Picture	Name	Qty
1		Trailer Coupler	1
3	VEVOR	User Manual	1

OPERATION



To open, pull up on coupler handle and rotate forward. Place coupler on ball. When ball is completely nested in ball socket, rotate coupler handle backward until handle is in locked position. Plug in the safety latch.

After towing for 50 miles, check coupler for tightness on ball. Always check tighness before towing. Be sure coupler handle is in locked position.

Installation:



MAINTENANCE

- 1. Please check that the bolts are tight before each use.
- 2. Do not overload.
- 3. Pay attention to rust prevention.

MADE IN CHINA



TechnicalSupport and E-Warranty Certificate www.vevor.com/support