

### 6x3x2M Greenhouse




#### **6X3X2 ASSEMBLY INSTRUCTIONS**




Base layout




Assemble for 2 sets floor tubes No3+No4+No3 use the shorter bolts, and the horizontal frame No4+No3+No3+No3+No3+No3+No3 together





Loosely assemble complete frame, before tightening all bolts in final position.




Loosely assemble complete frame, before tightening all bolts in final position.








# Step 5



For maximum stability of your polytunnel,we recommend digging a 20cm width trench around the base of the polytunnel and back



Put the frame inside the trench, ,filling with the soil



Tied the string in the back of the cover to the frame.

Use the ropes and stakes for four cormers of the greenhouse, to reinforce the stability of it.

#### **WARNING:**

Covering the roof carefully, makes all places in right position. as possible as not make the frame structure of the greenhouse out of the shape.

**DO NOT USE IN BAD WEATHER CONDITIONS**, such as rainstorm, hailstone, heay snow and heavy wind.