

# **VEVOR<sup>®</sup>**

**TOUGH TOOLS, HALF PRICE**

Technical Support and E-Warranty Certificate [www.vevor.com/support](http://www.vevor.com/support)

## **SHIPPING SCALE**

**MODEL:SF-808**

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

# VEVOR®

TOUGH TOOLS, HALF PRICE

## SHIPPING SCALE

MODEL:SF-808






### NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:


✉ [CustomerService@vevor.com](mailto:CustomerService@vevor.com)

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	<p>Warning-To reduce the risk of injury, user must read instructions manual carefully.</p>
	<p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.</p>
	<p>This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices</p>


## INSTRUCTIONS

Thank you very much for choosing this digital scale.weighing scales are precision instruments that should always be handled with care. Please read all of the instructions before using it.The information will help you achieve the best possible results.



A Weighing plate

B Indicator



C LCD display  
 D ON/OFF button  
 E MODE button

F TARE button  
 G Battery jar  
 H Battery cover

### SAVE THIS MANUAL

Capacity × Graduation	200kgx50g
Weighing units	Kg lb:oz lb
Weighing pan size	12" x 10"
Overload indication	[[O_Ld]]
Low voltage indication	[[LO]]
Optimum operating temperature	5°C-35°C
Power Supplier	4 x AAA(1.5V) batteries or AC adapter (110-240V AC to 5V DC)

## BUTTON FUNCTIONS

### Button Functions


**1.ON/OFF Button:** Pressing this button will turn the scale on and off

**2.TARE Button:** Pressing this button will tare the weight of the load. The tare function will eliminate the weight put on the scale, such as a container or vessel. This will give the weight only of the items added to the container.

**3.UNIT Button:** Pressing this button changes the unit of measure for the scale.

## OPERATION

1. Open the back cover and take out the indicator



Take out this indicator at the back of scale.

2.Press the ON/OFF button to switch the product on. The display shows "0.0" .

3. Place an item on the weighing plate. Wait for the readout on the display to stabilize.

4. After use, press the ON/OFF button to switch the product off.

## CALIBRATION

1. Put the scale on a flat platform.
2. Switch on the scale, press the “UNIT” for six seconds until LCD display show capacity and calibration weight.
3. Press TAER button to select calibration weight between 20kg 50kg.
4. Press UNIT button to choose calibration weight.
5. Place the standard weight on the pan according to the value shown on the LCD display.
6. After 2 to 3 seconds, the LCD display will show PASS indicating the scale has been calibrated successfully.
7. If you fail in calibration, the scale will show “Err”. You can press ON/OFF to stop calibration and try again.

## CARE INSTRUCTIONS

Don't put the scale on an uneven surface

Don't expose scale to moisture

Don't drop or mistreat the scale

Don't overload the scale. This will permanently damage it!

Don't leave weight on the scale when not in use.

Replace battery when the scale shows “LO” on the display.

	items	Description
1	Name	Shipping Scale
2	Model	SF-808
3	Parameter	Rating(s): 4x1.5AAA or 5Vdc, Capacity:200kg/440lb, Division:50g
4	Package Size	360x305x80mm
5	G.W.	2.4KG

**Importer:** WAITCHX

**Address:** 250 bis boulevard Saint-Germain 75007 Paris

**Importer:** FREE MOOD LTD

**Address:** 2 Holywell Lane, London, England, EC2A 3ET

**Manufacturer:** JiangYin SuoFei Electronic Technology Co.,Ltd.

**Address:** Building 70, Chuangrong Industrial City, Yucheng Street, Yuhuan City, Zhejiang Province

**Made In China**

<b>UK</b>	<b>REP</b>
-----------	------------

EUREP UK LTD  
UNIT 2264, 100 OCK STREET, ABINGDON  
OXFORDSHIRE ENGLAND OX14 5DH

<b>EC</b>	<b>REP</b>
-----------	------------

EUREP GmbH  
Unterlettenweg 1a, 85051  
Ingolstadt, Germany

**VEVOR<sup>®</sup>**

**TOUGH TOOLS, HALF PRICE**

**Technical Support and E-Warranty Certificate**

**[www.vevor.com/support](http://www.vevor.com/support)**